



NOTE: In the event of removing the turntable motor cover this part should be refitted using screw connection: LX-EZA045WRE0 (7-11)



MISCELLANEOUS



Actual wire harness may be different than illustration.

PACKING AND ACCESSORIES

