

Only for Fuzzi ovens

2441

2460

2470

2450

2550

2640

2641

4529

6330

3209

1000

3208

3209

3500

3200

1170

4210

4410

5060

5610

6911

6512

6511

6510

4520

5270

4900

4040

7740

1303

6330

1307

1302

6331

4060

0410

A

